

Lofting Instructions

Comstock, Middlebrook



HOUSING &
RESIDENTIAL LIFE

Rubber mallets can be checked out from the front desk.



- 1** Remove mattress and use mallet to loosen bed frame from bed ends.



- 3** Lift bed frame to 4th notch from top. Secure in place with mallet.



- 2** Attach safety rail to bed frame.



- 4** Add mattress.

Caution: Be careful not to hit the sprinklers while lifting the bed, and **ONLY** attempt with at least 2 people.

Need assistance? If you need something repaired or replaced in your room, submit a Fix It request: housing.umn.edu/FixIt